HTC Desire 820

Inserting your nano SIM and microSD cards

IMPORTANT: USE A STANDARD NANO SIM ONLY.
Don't cut a micro SIM or regular SIM card and insert it into the nano SIM slot. It's thicker than the standard nano SIM card and may get stuck in the slot.



1. Make sure your phone is off and is facing down. Open the slot cover with your thumb or finger.



2. Remove the nano SIM tray. To remove the tray, insert your fingertip in the small opening in the nano SIM slot and then pull the tray out.



3. Make sure the nano SIM tray is facing up. Place your nano SIM card into the tray with the gold contacts facing up and the cut-off corner facing out.



4. To reinsert the tray, center it first in the nano SIM slot, and then slide it in until it locks into place.



5. With your microSD™ card's gold contacts facing up, insert the microSD card into the bottom slot until it clicks into place.

6. To close the slot cover, slide the plastic hinge into the side and press the cover until it clicks into place.

Want some guidance on using your phone?

On your phone, check out our friendly walkthroughs in the Tips & Help app. For self-help in troubleshooting basic problems, you can use the HTC Guide app. Or go to www.htc.com/support/ to find tutorials, the user guide, FAQs, latest news, and more.

© 2014 HTC Corporation. All rights reserved.

HTC, the HTC logo, and HTC Desire are trademarks of HTC Corporation.

microSD is a trademark of SD-3C LLC.

All other company, product and service names mentioned herein are trademarks, registered trademarks or service marks of their respective owners.

htc.com

91H0xxxx-xxM Rev.A